

OWNER'S MANUAL

AIR-COOLED DIESEL GENERATOR SET

Model HDI 7000RWB



A Technology Corporation of America



Heavy Duty Power Systems
A Technology Corporation of America
Phone#:208-949-1121

PREFACE

Thank you for purchasing products from our company .We appreciate your business. The following manual is only a guide to assist you and is not a complete or comprehensive manual of all aspects of maintaining and repairing your generator. The equipment you have purchased is a complex piece of machinery. We recommend that you consult with a dealer if you have doubts or concerns as to your experience or ability to properly maintain or repair your equipment. You will save time and avoid the inconvenience of having to go back to the store if you choose to write or call us concerning missing parts, service questions, operating advice, and/or assembly questions. Our air-cooled diesel generators have some of the following features:

- Lightweight construction
- Air cooled
- Four-stroke diesel internal combustion engine
- Direct fuel injection system
- Recoil starter or an optional electric starter
- Large fuel tank
- Automatic voltage stabilizer
- NFB circuit protector
- AC and DC outputs
- Low oil pressure sensor

H.D brand air-cooled diesel generators are widely used when electrical power is scarce. Our generators provide a portable mobile solution in supplying power for field operations during project construction. Some other known applications include pipeline construction and metal welding when electrical power is not available.

This manual will explain how to operate and service your generator set.

If you have any questions or suggestions about this manual, please contact your local dealer or us directly. **Consumers should notice that this manual might differ slightly from the actual product as more improvements are made to our products. Some of the pictures in this manual may differ slightly from the actual product as well. H.D POWER reserves the right to make changes at any time without notice and without incurring any obligation.**

TABLE OF CONTENTS

Chapter 1 Technical Specifications and Data	1
1-1 Technical specifications and data.....	1
1-2 Basic operating parameters.....	2
1-3 General dimensions and overview of the generators.....	2
Chapter 2 Operating the Diesel Generator	3
2-1 Main points of safety during operation of the generator.....	3
2-2 Preparation before operation.....	4
2-3 Checking the operation of the diesel engine.....	7
2-4 Starting the generator set.....	7
2-5 Proper operation of the generator set.....	8
2-6 Loading.....	9
2-7 Stopping the generator.....	10
Chapter 3 Maintenance	11
3-1 Maintenance schedules.....	11
3-2 Storing for long periods of time.....	12
Chapter 4 Troubleshooting	13
4-1 Troubleshooting procedures.....	13
4-2 Questions and doubts.....	13
Chapter 5 Generator Parts Diagrams and Listings	14
Chapter 6 Circuit diagram	20

CHAPTER 1 TECHNICAL SPECIFICATIONS AND DATA

1-1 Technical specifications and data

H.D Single-cylinder diesel generator

Model Item	HDI7000BD	HDI 7000RWB
Rated frequency (Hz)	60	60
Rated voltage (V)	220、230、240、110/220、 115/230、120/240	380/220、400/230、420/240
Rated output power (kVA)	4.6	4.6
Max output power (kVA)	5.0	5.0
Rated rotation speed (rpm)	3600	3600
Power factor cosφ	1	1
Phase number	Single	Single
Pole number	2	3
Excitation Transistorized	self-excitation , Brushless	self-excitation constant voltage (AVR)
ATS type	without ATS	without ATS
Fuel consumption (g/kw.h)	340	340
Fuel tank capacity (L)(US.gal)	14.5(3.8)	14.5(3.8)
Continuous running time (hr)(at rated power)	8	8
Noise level [dBA/7m] (zero load~full load)	69-74	69-74
Net weight (kg)(US.lbs)	165(363)	165(363)
Overall dimension [mm](L×W×H)(US.inch)	920×520×700 (36.2×26.5 ×27.6)	920×520×700 (36.2×26.5 ×27.6)
Starter system	electric starter	electric starter
Fuel type	0# (summer), -10# (winter), -35#(chill cold) diesel	0# (summer), -10# (winter), -35#(chill cold) diesel
Lube oil brand	CD or better than CD	CD or better than CD
Engine model	CF186F(E)	CF186F(E)
Engine type	Single cylinder, 4-stroke,air-cooled,vertical, diesel engine	Single cylinder, 4-stroke,air-cooled,vertical, diesel engine
Bore × stroke(mm)	86×72	86×72
Displacement(cm ³)	0.418	0.418
Compression ratio	19: 1	19: 1
Rated power [kW(Hp)/rpm]	6.3(8.6)/3600	6.3(8.6)/3600
Max. power [kW(Hp)/rpm]	7.0(9.5)/3600	7.0(9.5)/3600
Rotation direction(from the flywheel)	clockwise	clockwise

Note: Get this power only after 30 hours' initial run.

1-2 Basic operating parameters


1-2.1 Under the given conditions, the generator will output the specified power in the table listed below.

Table 1

Height above sea level (ft)	Ambient temperature (° F)	RH
0	+60 (+20 ° C)	60%
<3280.8 (<1000 m)	41~104 (5-40 ° C)	90%

1-3 General dimensions and overview of the generators

1-3.1 HDI 7000RWB dimensions of the series generator.



1-4 Operation Instruction

Turn the switch “POWER” and circuit breaker switch “AC SW” to “OFF” position.see figure 1 as following:




Figure 1


Fill in small sum of fuel into the fuel tank, make sure fuel pipe is connected properly, and no leakage in fuel supply system. Fill in fuel to proper level.

Connect the positive(+) battery cable to the battery positive(+) terminal. Connect the other end of the positive (+) battery cable to the generator positive (+) terminal.

Connect the negative (-) battery cable to the battery negative (-) terminal. Connect the other end of the negative (-) battery cable to the generator negative (-) terminal.

1-4.1 How to start generator'


Turn the switch "POWER" to "ON" position. The controller is energized. It indicates "000V" by LED screen. Connect the plug of electrical appliances to the socket on the generator panel. Press the green button "ON" , the generator will start automatically. AC voltage is indicated by LED after generator starts.

Press the yellow button "MENU" , real-time voltage, currency, frequency and cumulative time is indicated orderly. Indicator lights of frequency and cumulative time will turn on in the right part of the panel.

If you need 120V AC output, please turn the transfer switch left to "120V" position, and turn circuit breaker to "ON" position. If you need AC 120/240V, please turn the transfer switch right to "120/240V" position, and turn circuit breaker to "ON" position.

When you use the transfer switch, please turn circuit breaker to "OFF" position at first.

1-4.2 How to stop and reset generator

Take off the load of generator; turn the circuit breaker to "OFF" position. Press the red button "OFF" , the generator will stop automatically. Then turn the switch "POWER" to "OFF" position.

When generator fails to start or when error happens, alarm light will stay on in the controller module, and fault code will be displayed in the LED. The fault code will tell you the probable reasons. Press the red button "OFF", reset the module, remove the fault code, and alarm light goes out at the same time. Re-start the generator after the fault is cleared.

If you want to lay the generator idle for a long time, please drain the fuel, disconnect the battery before the generator is put away.

1-4.3 Fault code

E01—start failure (Starting directive is sent to controller, but generator fails to start. The generator will not try to start generator before fault is cleared)

E02—voltage > 250V (The data is detected 5 seconds after generator starts)

E04—frequency >67Hz (The data is detected 5 seconds after generator starts)

E05—frequency<53Hz (The data is detected 5 seconds after generator starts)

E06—battery voltage >19V (The data is detected before starting,. The generator can not start if fault is inspected)

E07—battery voltage <10.5V (The data is detected before starting. The generator can not start if fault is inspected)

E08—low oil pressure

CHAPTER 2 OPERATING THE DIESEL GENERATOR

2-1 General main points of safety during operation of the generator set.

In order to operate the generator set safely, please follow all the instructions provided in this manual carefully. Doing so otherwise may lead to accidents or equipment damage.

2-1.1 Fire prevention

The proper fuel for the diesel generator set is light diesel fuel. Do not use gasoline, kerosene or other fuels other than light diesel fuel. Keep all flammable fuels away from the generator as the generator may spark and ignite these gases. In order to prevent fires from occurring and to provide enough ventilation for people and the machine, keep the diesel generator at least 1.5 meters away from buildings and or other equipment. Always operate your diesel generator on a level site. If the generator is operated on an incline, the lubricating system within the engine will not perform well and may lead to failure of the engine.

2-1.2 Prevention from inhaling exhaust gases.

Never inhale exhaust gases emitted by the engine. The exhaust gases contain toxic carbon monoxide. Never operate your generator in places with poor ventilation. In order to operate this machinery indoors, a suitable ventilation system for the building is required to draw the poisonous exhaust gases out.

2-1.3 Prevention from accidental burns

Never touch the muffler and its cover when the diesel engine is running. Never touch the muffler and cover after the diesel engine has been used, as the muffler remains hot for a good period of time.

2-1.4 Electric shock and short circuits

Never touch the generator if the generator is wet. Also never touch the generator if your hand is wet. Never operate your generator if the weather conditions call for any type of precipitation such as rain, snow, or fog. To prevent electrical shocks, the generator should be grounded. Use a lead to connect the grounding end of the generator to the grounding surface of choice. Please refer to Fig. 2-1 before beginning to use the electric generator.

Fig. 2-1

Note: When connecting devices to the generator, make sure all other devices are rated lower than the generators output. Any generator socket should not be overloaded over its regulated limit.



2-1.5 Other safety points

Before operating this generator, all operators should have a good knowledge of how to break the circuit if any accidents occur. Also, all operators should be familiar with all the switches and functions of the generator before using this machine. While operating the generator, wear safe shoes and suitable clothes during operation. Always keep children and animals away from the generator.

2-1.6 Battery

The electrolytic liquid of the battery also known as battery acid contains sulfuric acid. In order to protect your eyes, skin, and clothing, wears protective gear when working with the battery. If you come in contact with the electrolytic liquid, wash it immediately with clean water. Also, if the electrolytic liquid comes in contact with your eyes, see a doctor immediately.

2-2 Preparation before operation

2-2.1 Fuel choices and fuel treatment

Fuel tank


Use only light diesel fuel. The fuel should be filtered clean. Never let dust and water mix with fuel in the fuel tank. Otherwise it will clog the fuel lines and oil nozzles. It may also damage your pressure pump.

Note: It is dangerous to overfill the fuel tank. Never exceed the red piston in the filter.

Type	HDI 7000RWB	HDI 7000RWB
The effective volume of fuel tank: (L)(US. gal)	14.5 (3.8)	14.5 (3.8)

- a. After purchasing fuel, put it into a drum and let it sit for 3-4 days.
- b. 3-4 days later, insert half of the fuel sucker into the drum, (water and impurities stay in the lower portion of the drum)

NOTE: Never smoking near the opening of the fuel tank. Do not let sparks get near the fuel or fuel tank and do not overfill tank. After filling, tighten the fuel cap.



Air filter element

Do not wash the air filter. The element is made of dry material, which does not permit washing. When the output of the diesel engine is bad or the color of the exhaust gas is abnormal, replace the air filter element. Never start the diesel engine without the air filter.


Air filter




2-2.2 Filling engine oil

Remove the dipstick from the engine


Make sure the generator is on level ground, and fill the engine with 15W40 engine oil. Put the dipstick back into the hole to check the engine oil level.



Engine oil is the most important factor in determining the life of your generator engine. If you use poor engine oil or if you don't change the oil regularly, the piston and cylinder will wear easily or seize up. Also, the life of the other parts in your engine such as bearings, and other rotating parts will shorten considerably.



Although there is an alarm system to check for low oil pressure, it is always a good idea to check the amount of oil inside the engine. If the oil level is low, fill it before starting the engine. A good time to drain the oil from the engine is when the diesel engine is still hot. If the engine is fully cooled, it is more difficult to drain all the oil out or some impurities will remain in the engine.



Warning: Don't fill engine oil when diesel is operating.

2-2.3 Checking the air filter



(1) Loosen the butterfly nut, take the cover of the air filter off and take the air filter element out.

Do not use detergent to wash the air filter element. When the performance of the engine decreases or when the color of the exhaust gases is bad, exchange the filter element. Never start the engine without the air filter as foreign objects may enter the intake and damage the engine.

Air filter



(2) After replacing the air filter element, replace the cover and tighten the butterfly nut firmly.

Air filter cover

Use dry compressed air (with pressure about 1.96×10^5 Pa) to blow the dust out in the electric control cabinet and at the surface of the generator. Check to see how clean the surface of the sliding ring is. Check the pressure of the carbon brush. Also, check whether the position of the carbon brush at the slide ring is correct and the fixture is reliable with a good contact.

According to the electric wiring diagram, check to see whether the connecting wire is correct and the connected place is firm.

Use a $500 \text{ M } \Omega$ meter to measure the insulation resistance of the electrical part. The resistance should be no less than $5 \text{ M } \Omega$. When measuring devices, make sure the AVR is turned off. Otherwise, it will burn the AVR. (For the low noise set, the inspection may not be performed).

2-2.4 The fuel and oil in a new engine is drained before sold. Before you start the engine, please fill the fuel tank and engine oil first. Then, check to see if there are air bubbles in the engine. If there are, follow these procedures. Loosen the connecting nut between the fuel injector pump and fuel pipe. Bleed the air from the system until there are no more bubbles. Then replace the connecting nut and tighten it.

2-3 Checking the operation of the diesel engine

2-3.1 Low-pressure alarm system.

H.D diesel engines have a low-pressure sensor system where if the oil pressure drops too low, the sensor will shut the engine off. The purpose of having this system is to ensure that the engine does not seize up. If there is not enough oil in the engine, the temperature of the oil will be raised too high. On the contrary, if there is too much oil in the engine, the engine oil can slow the engine down considerably.

2-3.2 How to open the case door/cover

- (1) Open the case door: Pull the handle outward and open the door. Do these checks daily.
- (2) Loosen the outer cover bolt of the air filter and outer cover of the oil nozzle, and then check the air filter.
- (3) Check the outer cover of the oil nozzle. Loosen the butterfly nut and open the outer cover.



Knobhandle

2-3.3 Engine break in

When you purchase a brand new engine, the engine must be properly broken in. The break in period is about 20 hours.


- (1) Avoid overloading the engine when brand new
- (2) Change the engine oil according to specifications. An oil change for a brand new engine is about 20 hours or every month, an older engine, the oil change is about 100 hours or three months.

2-4 Starting the generator set

2-4.1 Starting.

Start the engine in accordance with procedures below:

- (1) Open the front door to put the speed handle to right side, namely "on" position.
- (2) Turn the ignition switch of the engine to the "Start" position for 1~2 seconds.
- (3) After starting the engine, loose the ignition switch and it will return to "On" position automatically, the engine start to work.
- (4) If fail to start, please restart the engine as above steps after 15 seconds.



Speed handle


2-4.2 Battery

1. Insert key into ignition and put it in the “off” position.
2. Put the speed handle in the “Run” position.
3. Turn the start switch clockwise to the “START” position.
4. After the diesel engine is started, remove your hand from the switch handle; the switch will automatically reset itself to the “ON” position.
5. If the engine is not starting after 10 seconds of cranking, wait about 15 seconds before trying it again. If you crank too long, the voltage of the battery will drop. This can lead to improper ignition. When the diesel engine is operating, let the ignition retain on the “ON” position.

Note: If you crank the starter too long, the battery may be drained too much to provide enough energy for proper engine ignition. Also, when the diesel engine is operating, let the key retain in the “ON” position.

Important Notice:

All of our units come with a maintenance free battery. You do not need to add any battery acid.




2-5 Proper operation of the generator set

2-5.1 Operating the diesel engine

1. Pre-heat the diesel engine for 3 minutes under no load conditions.
2. First check the height of the lubricating oil level, if it is low, refill it. Our diesel engines are equipped with an alarm system that will notify you if the oil pressure is too low. The alarm system will shut down the engine if the oil pressure is too low.



3. Do not adjust the speed limit regulation bolt or the fuel adjustment bolt. These bolts have been set by the factory already, changing them will affect the properties of the engine performance.



High-pressure fuel pipe bolt

2-5.2 Checks during engine operation

1. Check to see if there are abnormal noises.
2. Check to see if the performance is good or bad
3. Check the color of the exhaust gases (whether it is too black or too white). If any of these conditions exist, stop the engine and find the cause of the problem. If no problems are found, please contact your local dealer or our nearest company branch.

2-6 Loading

2-6.1 Load conditions

Exert loads in accordance with the specified parameters.

2-6.2 Output of electricity

1. Raise the revolutions per minute (turn the speed handle to the max setting) of the generator to get the maximum power out of the generator. If not, the automatic voltage regulator device will excite and doing this for long periods of time will cause the AVR to burn. For the rated speed of the generator, please refer to Chapter 1, item 1-1 technical specification and data.
2. Observe the pointer of the voltmeter; it should point to 240 V 5% (60Hz). Meanwhile put the switch in the GEN (generator) position. The AC voltage from the socket of the power supply can be output.
3. When connecting devices to the generator, make sure to connect these devices in order. Connect the large loads onto the generator first. If everything is functional, smaller loads can then be added. If the generator shuts off, it may be because the load being drawn by all the various devices are too high. In this event, decrease the number of small devices until everything is functional. The total drawn power should not exceed the maximum output power of the generator. Please see Table 1-1 for technical specifications of what the generator can output. In order to reset the generator after overdrawn power, let it sit for several minutes. If the indication of the voltmeter is too high or too low, adjust the speed accordingly. If there are problems, stop the generator immediately and fix the issue.
4. During operation, the generator should be in a place that has very good ventilation. Never cover the engine to solve a ventilation problem, as this will damage your equipment.

Note: Do not start more than two devices simultaneously. Each device should be started one by one to prevent overloading the generator.

The generator should be running at 3600 revolutions per minute in order to achieve the (60 Hz) frequency. The speed of the engine can be adjusted from the speed governor.

2-6.3 Charging the battery

1. For the electric starter on the generator sets, the 12V battery is automatically charged through the regulator on the side of the engine when it is running.
2. If the generator is not used for long periods of time, the battery should be disconnected to avoid energy loss from the battery.
3. Do not connect the negative and positive terminals of the battery together at any time. Doing so will damage the battery and cause serious injuries.
4. Do not reverse the polarities when attaching the battery cables to the battery. Doing so will damage both the battery and the electric starter.
5. When charging the battery, the battery produces flammable gases. Do not smoke, let flames, and sparks get near the battery while it is charging as this may cause a fire.


To avoid sparking while connecting the cables to the battery, first, connect the cables to the battery then to the motor. To disconnect battery cables, first disconnect the motor end of the cable.

2-7 Stopping the generator

1. Take the electrical load off the generator.
2. Put the speed handle in the "RUN" position and let the engine run for 3 minutes after unloading. Do not stop the diesel engine immediately let it warm down. Stopping the diesel engine suddenly may raise the temperature of the engine abnormally and lock the nozzle and damage the diesel engine.

Note:

1. If you cannot stop the engine with a load on it, then remove the load first than stop the engine.
2. Press down on the brake handle.
3. If equipped with an electric starter, turn the key to the "Off" position.
4. Put the fuel handle to the "S" position.



Speed handle

CHAPTER 3 MAINTENANCE

3-1 Maintenance schedules

Keeping your generator well maintained will prolong the life of your generator. Everything needs to be checked including the diesel engine, generator, control cabinet, and frame. For overhauling procedures, please refer to the instruction manual of the relative subassembly. If you need these manuals, please call our company and we will send you one.

Before starting the maintenance, make sure the diesel engine is off.

Please refer to the Table 3-1 for the proper maintenance schedule.

Table 3-1. Maintenance schedule for diesel generator set


Time Item	Everyday	After 1 month or 50hours	Every 3 month or 200 hours	Every 6 month or 400 hours	Every 1year or 1000 hours
Check the fuel level and refill	○Before starting				
Drain the fuel tank		○			
Check and fill enough engine oil	○				
Clean the fuel filter			○		
Check fuel oil leakage	○after every operating				
Check and screw each fastened part	○			●screw the bolt of cylinder head firmly	
Check injector				●	
Check injection pump					●
Check fuel pipe				●If necessary exchange it	
Check the lube. oil level in the oil pan and refill	○before starting				
Replace the lube. oil		○the first time	○the second time and afterward		
Clean lube. Oil filter		○the first time	○the second time and afterward		
Check the air cleaner element		○the first time	○the second time and afterward		
Change the core of air filter	If damaged or smeary , change it in time				
Check the battery liquid level and refill	○				
Adjusting the intake and exhaust valve clearance		●the first time		●the second time and afterward	
Grind air intake and air exhausted gate					●
Exchange piston ring					●
Check electric brush and slide ring				●	
Check insulation resistance	The time of stop is over 10 days ○				

Note: the quality period of the injector and injection pump is 1500 hours or two years. There into,● means it should operate with special tools, or can be checked by dealer.

MAINTENANCE

3-1.1 Changing the engine oil (every 100 hours)

Take the oil cover off. Remove the oil drain plug when the diesel engine is still hot. Be careful of hot oil and hot engine as you may get burned. The bolt is located at the bottom of the cylinder. After draining the oil, put the bolt back and tighten it. Then fill with the proper engine oil to the proper level.



3-1.2 Air filter maintenance schedule

1. Clean air-filter every 6 months or 500 hours of operation.
2. If necessary, exchange it.
3. Do not use detergent to clean air filter element.

Note: Never start the engine without the air filter. This can cause serious damage to the engine if foreign objects enter the intake system. Always change the air filter on time.

3-1.3 Fuel filter maintenance

1. The fuel filter should be cleaned often to keep the engine running at maximum performance.
2. The recommended time period for cleaning the fuel filter is 6 months or 500 hours of operation.
 - a. To do this, first drain the fuel from the fuel tank.
 - b. Loosen the small screws on the fuel switch and remove the fuel filter from the port. Use diesel fuel to clean the fuel filter. Also, remove the fuel injector and clean the carbon deposit around it. The recommended time period for this is 3 months or 100 hours.

3-1.4 Cylinder head bolt tensions

The cylinder head bolts should be tightened to specifications please refer to the diesel engine manual for specifications and the special tools required to do this.

3-1.5 Battery check

Make sure the battery acid is full. The engine uses a 12V battery. Due to numerous starting cycles, the battery acid may be used up. Also, before filling, verify that the battery is not damaged in any way. Add distilled water to the battery when filling. Perform checks on the battery once a month.

3-2 Storing for long periods of time

If your generator needs to be stored for long periods of time, the following preparations should be made.

1. Start the diesel engine for 3 minutes then stop it.
2. When the engine is still hot, change the engine oil with new engine oil of the proper grade.
3. For electric started generator, press the decompression handle down and crank the engine for 2-3 seconds. To do this, put the starter switch in the "Start" position. (Do not start the diesel engine)
4. Clean the engine and store it in a dry place.

CHAPTER 4 TROUBLESHOOTING

4-1 Troubleshooting procedures

	Causes of malfunction	Remedy
Diesel cannot be started.	Not enough fuel	Add enough fuel
	The switch of fuel is not at "OPEN" position.	Turn the switch of fuel to "OPEN" position.
	High-pressure pump and nozzle do not inject fuel or the injected amount is less.	Disassemble the nozzle and adjust it at test table.
	Speed control lever is not at "RUN" position.	Turn speed control lever to "RUN" position.
	Check level of lubrication oil.	The standard oil amount of lubricating oil should be between high graduation "H" and low graduation "L".
	It is not quick and powerful to pull reactive starter.	Start diesel engine in accordance with the requirements of "start operation procedures".
	Nozzle exist dirt.	Clean the nozzle.
	Accumulator has not electricity.	Charge the accumulator or exchange it.
Generator cannot generate electricity and has not welding voltage	Master switch (NFB) is not be switched on.	Turn master switch handle to "ON" position.
	Carbon brush of generator was worn. The contact is bad.	Exchange the carbon brush.
	The contact of socket is bad.	Adjust the contact feet of socket.
	The rated revolution of engine cannot be reached.	Make it reach to the rated revolution in accordance with the requirements.
	AVR automatic governor is damaged.	Exchange it.
	The potentiometer of current regulation for electric welding is damaged.	Exchange it.

If you are still having trouble, please contact with your nearest dealer or with our company directly if necessary.


4-2 Questions and doubts

If you do not understand anything or have any questions, please feel free to contact your local dealer or with our company directly. Below is a list of some information you should have ready before contacting your local dealer or us.

1. Model of diesel engine generator and engine model number.
2. State of residency.
3. Number of hours of operating equipment along with the problem that occurred.
4. A detailed condition and time when the problem occurred, in other words, climate and atmosphere.

CHAPTER 5 GENERATOR PARTS DIAGRAMS AND LISTINGS

Figure 5-1. Overall view of engine generator assembly



GENERATOR PARTS DIAGRAMS AND LISTINGS

Table 5-1. Please refer to figure 5-1 for illustration


No	Part Description	Quantity	Part Code
1	Silencer cover	1	HDI 7000RWB-001
2	Silencer bend	1	HDI 7000RWB-002
3	Left board of cover	1	HDI 7000RWB-003
4	Back door of cover	1	HDI 7000RWB-004
5	Fixing sleeve for observing bore	1	HDI 7000RWB-005
6	Fixing sleeve for input of fuel tank	1	HDI 7000RWB-006
7	Main cover	1	HDI 7000RWB-007
8	Switch of front door	1	HDI 7000RWB-008
9	Air filter baffle	1	HDI 7000RWB-009
10	stationary rings of generators	1	HDI 7000RWB-010
11	Right board of cover	1	HDI 7000RWB-011
12	Output panel assembly	1	HDI 7000RWB-012
13	Cover of observing bore for air filter	1	HDI 7000RWB-013
14	Cover of fuel tank assembly	1	HDI 7000RWB-014
15	Buoy for oil level indication	1	HDI 7000RWB-015
16	Fuel tank(not assembly)	1	HDI 7000RWB-016
17	Lining of absorbing mat	4	HDI 7000RWB-017
18	Shock absorbing mat	4	HDI 7000RWB-018
19	Clip ϕ 9	4	HDI 7000RWB-019
20	Clip ϕ 13	4	HDI 7000RWB-020
21	Fuel inlet pipe I (ϕ 13)	1	HDI 7000RWB-021
22	Fuel filter assembly with cover	1	HDI 7000RWB-022
23	Fuel inlet pipe II (ϕ 13)	1	HDI 7000RWB-023
24	Fuel leak-off pipe	1	HDI 7000RWB-024
25	Cover of U-type chamfer	1	HDI 7000RWB-025
26	U- type chamfer	1	HDI 7000RWB-026
27	Support of U-type chamfer	1	HDI 7000RWB-027
28	Moire output pipe	1	HDI 7000RWB-028
29	Gasket of silencer	1	HDI 7000RWB-029
30	Upper silencer	1	HDI 7000RWB-030
31	Low silencer	1	HDI 7000RWB-031
32	Back cover of alternator	1	HDI 7000RWB-032
33	Bracket of classis	1	HDI 7000RWB-033
34	Shock absorbing mat of generators	4	HDI 7000RWB-034
35	Tow structure	1	HDI 7000RWB-035
36	Rectify bridge	1	HDI 7000RWB-036
37	Wiring seat3×2	1	HDI 7000RWB-037
38	Battery cable(set)	1	HDI 7000RWB-038
39	Chassis	1	HDI 7000RWB-039
40	Rolling wheel on chassis(4 inch)	4	HDI 7000RWB-040
41	Flat washer	8	HDI 7000RWB-041
42	Pin 3×25	4	HDI 7000RWB-042
43	Motherboard of accumulator	1	HDI 7000RWB-043
44	Accumulator (maintenance free)	1	HDI 7000RWB-044
45	hook type bolt of battery	2	HDI 7000RWB-045
46	Pressing plate of accumulator	1	HDI 7000RWB-046

GENERATOR PARTS DIAGRAMS AND LISTINGS

No	Part Description	QU.T	Part Code
47	clamp of accumulator with bolt and nut	2	HDI 7000RWB- 047
48	cover of clamp of accumulator	2	HDI 7000RWB- 048
49	Alternator assembly	1	HDI 7000RWB- 049
50	Output wind leading shaft	1	HDI 7000RWB- 050
51	Manostat	1	HDI 7000RWB- 051
52	Gasket of output bore	1	HDI 7000RWB- 052
53	Diesel engine	1	HDI 7000RWB- 050
54	Capacitor/AVR	1	HDI 7000RWB- 054
55	Intake wind leading shaft	1	HDI 7000RWB- 055
56	Pressing plate of high pressure fuel pipe	1	HDI 7000RWB- 056
57	shock preventing mat of intake wind leading shaft	1	HDI 7000RWB- 057
58	shock preventing holder of intake wind leading shaft	1	HDI 7000RWB- 058
59	Cover of wheel	4	HDI 7000RWB- 059
60	Fuel leak-off pipe of pipe tee ϕ 9	1	HDI 7000RWB- 060
61	Pipe tee	1	HDI 7000RWB- 061
62	Fuel inlet pipe of pipe tee ϕ 13	1	HDI 7000RWB- 062
63	Support of manostat	1	HDI 7000RWB- 063
64	lead of manostat	1	HDI 7000RWB- 064
65	Electromagnet	1	HDI 7000RWB- 083
66	Accelerator electromagnet	1	HDI 7000RWB- 084
67	Pulling wire for turn-off	1	HDI 7000RWB- 085
68	Pulling wire for throttle	1	HDI 7000RWB- 086
69	Pulling role for accelerator	1	HDI 7000RWB- 087
A	Bolt M6 \times 16with flat washer	54	HDI 7000RWB- 065
B	Heterotypic bolt M6 \times 8	6	HDI 7000RWB- 066
C	Heterotypic bolt M6 \times 14	6	HDI 7000RWB- 067
D	Heterotypic bolt M6 \times 22	6	HDI 7000RWB- 068
E	Bolt M10 \times 45with flat washer and spring washer	4	HDI 7000RWB- 069
F	Bolt M6 \times 16	4	HDI 7000RWB- 070
G	Bolt M8 \times 25	5	HDI 7000RWB- 071
H	Bolt M6 \times 12	17	HDI 7000RWB- 072
I	Bolt M5 \times 8	2	HDI 7000RWB- 073
J	Heterotypic nut M6	34	HDI 7000RWB- 074
K	Nut M8 with flat washer ϕ 8and spring washer ϕ 8	6	HDI 7000RWB- 075
L	Nut M10with flat washer ϕ 10and spring washer ϕ 10	12	HDI 7000RWB- 076
M	Bolt M5 \times 12	2	HDI 7000RWB- 077
N	Bolt M6 \times 22	2	HDI 7000RWB- 078
O	crossed bolt M4 \times 22 with flat washer and spring washer	5	HDI 7000RWB- 079
P	Nut M4	5	HDI 7000RWB- 080
Q	crossed bolt M5 \times 12	4	HDI 7000RWB- 081
R	Nut M5	4	HDI 7000RWB- 082

* Please notice that Item 65,66,67,68 and 69 only can be supplied to the generators with mechanical injection pump. If you use electromagnetic pumps, these parts are not necessary. Please consult the dealer before make the orders.

Figure 5-2. *Electric panel parts drawing*



GENERATOR PARTS DIAGRAMS AND LISTINGS

Table 5-2. Please refer to Figure 5-2

Number	Part Description	Quantity	Part Code
1	Nut M4(GB/T6170-2000)	6	HDI 7000RWB -C-001
2	Electric start switch	1	HDI 7000RWB -C-002
3	Square American type-socket	1	HDI 7000RWB -C-003
4	Overload protector(20A)	1	HDI 7000RWB -C-004
4-1	Overload protector(30A)	1	HDI 7000RWB -C-005
5	B-type aluminum panel	1	HDI 7000RWB -C-006
6	Bolt M4×12(GB/T819.1-2000)	6	HDI 7000RWB -C-007
7	Bolt M6×10 (GB/T819.1-2000)	4	HDI 7000RWB -C-008
8	Voltmeter	1	HDI 7000RWB -C-009
9	Bolt M3×16(GB823-88)	2	HDI 7000RWB -C-010
10	Digital Timing	1	HDI 7000RWB -C-011
11	Red wire holder(107)	1	HDI 7000RWB -C-012
12	Black wire holder(107)	1	HDI 7000RWB -C-013
13	Bolt M4×25(GB/T818)	2	HDI 7000RWB -C-014
14	plate Washer4	9	HDI 7000RWB -C-015
15	Nut M6 (GB/T6170)	2	HDI 7000RWB -C-016
16	DC fuse assembly	2	HDI 7000RWB -C-017
17	Nut M3 (GB/T6170-2000)	2	HDI 7000RWB -C-018
18	Transfer switch302/25A	1	HDI 7000RWB -C-019
19	American type 4-hole unit loose socket	1	HDI 7000RWB -C-020
20	Bolt M6×26 (GB/T5787-1996)	1	HDI 7000RWB -C-021
21	3-hole unit loose socket	1	HDI 7000RWB -C-022
22	Breaker(DZ216-63/2P/18.5A)	1	HDI 7000RWB -C-023
23	Nut M4 (GB/T6170-2000)	9	HDI 7000RWB -C-024
24	Indicating lamp of power supply(12V)	1	HDI 7000RWB -C-025
25	Low-oil protection indicating lamp(12V)	1	HDI 7000RWB -C-026
26	2P support of breaker	1	HDI 7000RWB -C-027
27	Fuse 10A	2	HDI 7000RWB -C-028
28	Key	1	HDI 7000RWB -C-029
29	bolt to the grounded	1sets	HDI 7000RWB -C-030
30	rectifier(12V)	1	HDI 7000RWB -C-031

Figure 5-3. Generator head assembly






Table 5-3. Please refer to figure 5-3

Number	Part Description	Quantity	Part Code
1	Front end cover	1	HDI 7000 RWB-B-001
2	Diode 3510	1	HDI 7000 RWB-B-002
3	Bolt M5 x 16	2	HDI 7000 RWB-B-003
4	Fan Blade	1	HDI 7000 RWB-B-004
5	Bearing 6204(GB/T 307)	1	HDI 7000 RWB-B-005
6	Rotor Unit	1	HDI 7000 RWB-B-006
7	Center bolt M10 x 216 (GB/T5789-1986)	1	HDI 7000 RWB-B-007
8	Guard board of motor	1	HDI 7000 RWB-B-008
9	Installing bolt M6×180(GB/T5789-1986)	4	HDI 7000 RWB-B-009
10	Capacitance 30mf	1	HDI 7000 RWB-B-010
11	Wiring seat	1	HDI 7000 RWB-B-011
12	Heterotypic bolt M5×14	6	HDI 7000 RWB-B-012
13	Stator unit	1	HDI 7000 RWB-B-013
14	Dust cover	1	HDI 7000 RWB-B-014

CHAPTER 6 CIRCUIT DIAGRAM



switch list

contact switch	A	B	C	D	E
0 stop				⊖	
I run	⊖	⊖			
II start	⊖	⊖	⊖		

main breaker collocate list

model	main breaker
HDI 7000RWB	20A