



HONDA Engine Parts List

Model HD5510TH-E

REF. NO.	PART NO.			DESCRIPTION	QTY.
	Model HD5510TH-E	Model HD5510TH-E	Model HD5510TH-E		
1	RZ168F-I-001	*	*	Fuel hose clip	2
2	RZ168F-I-002	*	*	Fuel hose	1
3	RZ168F-I-003	*	*	Fuel outlet joint	1
4	RZ168F-I-004	*	*	Fuel tank cap	1
5	RZ168F-I-005	*	*	Fuel filter	1
6	RZ168F-I-006	*	*	Fuel tank	1
7	RZ168F-I-007	*	*	Carburetor spring	1
8	RZ168F-I-008	*	*	Governing spring	1
9	RZ168F-I-009	*	*	Governor arm	1
10				Nut M6	5
11	RZ168F-I-010	*	*	Clip	1
12	RZ168F-I-011	*	*	Governor shaft	1
13	RZ168F-I-012	*	*	Carburetor connecting rod	1
14				Screw M6x12	13
15	RZ168F-I-013	*	*	Governor arm screw	1
16	RZ168F-I-014	*	*	Throttle control rack	1
17	RZ168F-I-015	*	*	Governor shaft washer	2
18	RZ168F-I-016	*	*	Rope handle	1
19	RZ168F-I-017	*	*	Starter case	1
20	RZ168F-I-018	*	*	Starter spring	1
21	RZ168F-I-019	*	*	Rope	1
22	RZ168F-I-020	*	*	Drum sheave	1
23	RZ168F-I-021	*	*	Spring	2
24	RZ168F-I-022	*	*	Drive pawl	2
25	RZ168F-I-023	*	*	Pawl guide	1
26	RZ168F-I-024	*	*	Setting screw	1
27	RZ168F-I-025	*	*	Engine switch	1
28	RZ168F-I-026	*	*	Fan case	1
29	RZ168F-I-027	*	*	Flywheel nut M14	1
30	RZ168F-I-028	*	*	Starting hub	1
31	RZ168F-I-029	*	*	Cooling fan	1
32	RZ168F-I-030	*	*	Flywheel	1
33	RZ168F-I-031	*	*	Air shroud	1
34	RZ168F-I-032	*	*	Oil seal 22x41.3x6	2
35	RZ168F-I-033	*	*	Diode rack	1
36	RZ168F-I-034	*	*	Diode	1
37	RZ168F-I-035	*	*	Drain plug	2
38	RZ168F-I-036	*	*	Drain plug washer	2
39	RZ168F-I-037	RZ168F-II-001	RZ170F-001	Crankcase	1
40	RZ168F-I-038	*	*	Ball bearing	2
41	RZ168F-I-039	*	*	Oil level sensor	1
42	RZ168F-I-040	*	*	Governing gear	1
43	RZ168F-I-041	*	*	Flyweight pin	2
44	RZ168F-I-042	*	*	Governing gear shaft	1
45	RZ168F-I-043	*	*	Governing gear shaft circlip	1
46	RZ168F-I-044	*	*	Flyweight	2
47	RZ168F-I-045	*	*	Washer	1
48	RZ168F-I-046	*	*	Collar	1
49	RZ168F-I-047	RZ168F-II-002	**	Crankshaft assembly	1
50	RZ168F-I-048	*	*	Crankcase gasket	1
51	RZ168F-I-049	*	*	Oil gauge	1
52	RZ168F-I-050	*	*	Oil gauge seal	2
53	RZ168F-I-051	*	*	Crankcase cover	1
54	RZ168F-I-052	*	*	Screw M8x32	6

* The part number same as Model RZ168F-I ** The part number same as Model RZ168F-II

Please provide following information for ordering parts and maintenance:

- . Model number
- . Part description, reference and part number as shown in parts list



Technology Corporation of America

HONDA Engine Parts List

Model HD5510TH-E

REF. NO.	PART NO.			DESCRIPTION	QTY.
	Model HD5510TH-E	Model HD5510TH-E	Model HD5510TH-E		
55				Screw M6x8	5
56	RZ168F-I-053	*	*	Air cleaner cover nut	1
57	RZ168F-I-054	*	*	Washer	1
58	RZ168F-I-055	*	*	Gasket	1
59	RZ168F-I-056	*	*	Air cleaner cover	1
60	RZ168F-I-057	*	*	Air cleaner element	1
61	RZ168F-I-058	*	*	Element rack	1
62	RZ168F-I-059	*	*	Air cleaner housing	1
63				Screw M6x25	3
64	RZ168F-I-060	*	*	T. C. I. Unit	1
65	RZ168F-I-061	*	*	Dowel pin	2
66				Cylinder screw M8x55	4
67	RZ168F-I-062	*	*	Carburetor washer	1
68	RZ168F-I-063	*	*	Choke level	1
69	RZ168F-I-064	RZ168F-II-003	**	Carburetor	1
70	RZ168F-I-065	*	*	Carburetor gasket	1
71	RZ168F-I-066	*	*	Carburetor connector	1
72	RZ168F-I-067	*	*	Connector gasket	1
73	RZ168F-I-068	*	*	Carburetor bolt M6x113	2
74	RZ168F-I-069	*	*	Breather tube	1
75	RZ168F-I-070	*	*	Cylinder head cover	1
76	RZ168F-I-071	*	*	Cylinder head cover gasket	1
77	RZ168F-I-072	*	*	Exhaust valve cap	1
78	RZ168F-I-073	*	*	Intake valve retainer	1
79	RZ168F-I-074	*	*	Exhaust valve Retainer	1
80	RZ168F-I-075	*	*	Valve spring	2
81	RZ168F-I-076	*	*	Spark plug	1
82	RZ168F-I-077	RZ168F-II-004	**	Cylinder head	1
83	RZ168F-I-078	RZ168F-II-005	RZ170F-002	Cylinder gasket	1
84	RZ168F-I-079	*	*	Intake valve	1
85	RZ168F-I-080	*	*	Exhaust valve	1
86	RZ168F-I-081	*	*	Valve lifter	2
87	RZ168F-I-082	RZ168F-II-006	**	Camshaft assembly	1
88	RZ168F-I-083	*	*	Dowel pin	2
89	RZ168F-I-084	*	*	Valve clearance adjusting nut	2
90	RZ168F-I-085	*	*	Rocker arm seat	2
91	RZ168F-I-086	*	*	Rocker arm	2
92	RZ168F-I-087	*	*	Rocker arm bolt	2
93	RZ168F-I-089	*	*	Push rod guide	1
94	RZ168F-I-090	*	*	Push rod	2
95	RZ168F-I-091	*	*	Crankshaft key	1
96	RZ168F-I-092	*	*	Screw M5x8	4
97	RZ168F-I-093	*	*	Muffler protector	1
98	RZ168F-I-094	*	*	Muffler	1
99	RZ168F-I-095	*	*	Nut M8	2
100	RZ168F-I-096	*	*	Exhaust gasket	1
101	RZ168F-I-097	*	*	Exhaust bolt	2
102	RZ168F-I-098	*	*	Air shroud	1
103	RZ168F-I-099	*	RZ170F-003	Piston ring set	1
104	RZ168F-I-100	RZ168F-II-007	RZ170F-004	Piston	1
105	RZ168F-I-101	*	*	Piston pin circlip	2
106	RZ168F-I-102	*	RZ170F-005	Piston pin	1
107	RZ168F-I-103	*	*	Connecting rod assembly	1
108	RZ168F-I-104	*	*	Oil filling plug	1

* The part number same as Model RZ168F-I ** The part number same as Model RZ168F-II

Please provide following information for ordering parts and maintenance :

. Model number

. Part description ,reference and part number as shown in parts list